KROSS STUDIO

MT1: CHRONOMÈTRE TOURBILLON 7 JOURS

USER MANUAL

TABLE OF CONTENTS

MT1: CHRONNOMÈTRE TOURBILLON 7 JOURS

Overview 3

Movement winding 5

Time setting 6

Interchangeable straps 7

Buckle opening 8

Buckle release 8

GENERAL

Regular care 9

Tech specs 10

Warranty 11

MT1: CHRONOMÈTRE TOURBILLON 7 JOURS

FRONT

1 Case

2 Dial

3 Hour hand

4 Minute hand

5 Flying tourbillon cage



MT1: CHRONOMÈTRE TOURBILLON 7 JOURS

BACK

6 Time set push button

7 D-ring crown

8 Strap release push buttons



MOVEMENT WINDING

The KS 7'010 manual-winding mechanical movement delivers a 7-day power reserve. After this period, you must wind your watch to provide the necessary energy for it to run.

In order to maintain perfect symmetry, the case has no crown at 3 o'clock. It is ingeniously centered on the back of the case. This mechanism enables faster winding than with a traditional crown.

To wind your watch, use a finger to rotate the crown clockwise until you feel some resistance, meaning that the watch has been wound. To fully wind your watch, 23 complete turns are needed.



TIME SETTING

To set the time, press the push button located at 3 o'clock on the case. A red indicator will appear in the time-setting window, confirming that the system is engaged. Then, rotate the crown on the back of the watch clockwise until the exact time is reached. Press the push button once more to disengage the time-setting system. The disappearance of the red indicator confirms that the system has been properly deactivated.

Note: if the time-setting system remains engaged, the watch will stop running. In this case, press the push button again to restart the movement.

Note:
You might turn the crown counterclockwise. In this case, go back 10 minutes before the actual time. Then, turn it clockwise until adjusting the exact time. It enables the gear train to go back to its functioning position.



INTERCHANGEABLE STRAPS

The MT1: Chronomètre Tourbillon 7 Jours is equipped with an interchangeable strap system, a practical feature where two quick-release buttons are hidden on the underside of the case.

Push each button to release the strap.



BUCKLE OPENING

Press simultaneously the two push buttons located on the sides of the clasp to open the buckle.



BUCKLE RELEASE

To detach the buckle, no tools are required. Simply pull the lever located under the clasp and it will release the strap.

To fix the buckle, start by inserting the right side of the buckle on the spring bar. Pull the lever and insert the left side.

Make sure the spring bar is securely in place by pulling few times the strap.



REGULAR CARE

REGULAR CARE OF THE MT1: CHRONOMÈTRE TOURBILLON 7 JOURS

The tourbillon remains one of the main horological complications and bears the mark of the most talented watchmakers. Caution and care are required to ensure the longevity of your watch. To handle it properly, a set of gloves and a soft microfiber cloth are provided in a box along with your MT1: Chronomètre Tourbillon 7 Jours. We strongly recommend wearing gloves every time the watch is manipulated for winding or time setting. It will enable a better gripping and help prevent any risk of scratching.

The watch has a water resistance of 30 meters. We recommend avoiding sea water. Clean regularly your watch by wiping down carefully with the soft microfiber cloth. If needed, you may use a solvent-free cleaner to spray on the cloth. Do not spray any liquid directly on the watch.



TECH SPECS

MT1: CHRONOMÈTRE TOURBILLON 7 JOURS

Parts
277

Movement

Caliber
KS 7'010 MT

Functions
Hours and minutes in the center, small seconds via the tourbillon cage at 06:00

Parts
217

Jewels
31

Power reserve
7 days

Frequency
21'600bph / 3Hz

Case

Materials
Grade 5 titanium

Water resistance
30m or 3ATM

Diameter
44mm

Thickness
15.30mm

Thickness without crystal
10.30mm

Case back

Material
Engraved grade 5 titanium

Interchangeable straps

Each timepiece comes with two customized set of straps.

The deployant buckle clasp is in grade 5 titanium

WARRANTY

On the day of purchase, the authenticity certificate must be duly dated and bear the official stamp of Kross Studio or the authorized retailer in order to serve as Warranty Certificate. This Kross Studio product holds an Individual Identification Number (IIN) that will be needed for every communication with Kross Studio. In the event of loss of this IIN, please contact the Kross Studio after-sales team: sales@kross.studio.

Kross Studio undertakes to repair or replace the defective product according to its judgement in line with the warranty terms below. Your watch is guaranteed against all manufacturing defects for a period of two years from the date of purchase, provided that the product was purchased from an authorized retailer or from Kross Studio. Repairs within the framework of the warranty must be carried out by Kross Studio or an authorized service center. Products that are repaired or exchanged may contain new and/or reused components.

WARRANTY EXTENSION

To register your product, visit:
kross-studio.ch/en/register-your-product

Follow the registration process. A warranty extension of 3 years will be delivered, granting a total warranty of 5 years from the date of purchase.

INTERNATIONAL WARRANTY CONDITIONS

End clients who have acquired a Kross Studio product are covered by this warranty in all countries with an approved Kross Studio repair center or approved Kross Studio retailer. The conditions of the warranty are specific to Kross Studio only. In order to benefit from the warranty coverage, end clients must present the original purchase invoice (namely the invoice received at the time the new product was first purchased by the end client).

We recommend a complete overhaul of the watch every 5 years. For any repair or service during the warranty period please contact the Kross Studio after-sales team: **sales@kross.studio**

The warranty does not cover damage caused by inappropriate use or handling of the watch, please refer to the User Manual for a good manipulation of your watch.

WARRANTY

THE INTERNATIONAL WARRANTY DOES NOT INCLUDE:

- Normal wear and aging of parts;
- Abnormal use or absence of regular maintenance of the watch;
- Moisture infiltration in the case and effects of oxidation;
- Defects results from magnetic fields or climatic conditions;
- Alterations, manipulations, disassembly or repairs undertaken by anyone other than an authorized service center or Kross Studio;
- Watches whose serial number or any other identification mark has been erased or altered;
- Straps;
- Theft or loss.